


EXPLODED VIEW



PARTS LIST

pos	description	q' ty	pos	description	q' ty
1	oil seal	1	25	rear end plate	1
2	screw	4	26	end plate pin	1
3	spring washer	8	27	end plate bearing	1
4	hex flange nut	4	28	rear cover gasket	1
5	front motor housing	1	29	screw	4
6	hammer case gasket	1	30	trigger	1
7	bushing	1	31	trigger pin	2
8	anvil ring	1	32	rear cover	1
9	O-ring	3	33	screw	1
10	anvil	1	34	O-ring	1
11	hammer frame lining	1	35	steel ball	1
12	hammer	1	36	spring	1
13	hammer cage	1	37	knob limit pin	1
14	hammer frame	1	38	knob pin	1
15	housing	1	39	knob	1
16	screw	4	40	reverse knob	1
17	spring washer	4	41	reverse valve bushing	1
18	handle	1	42	reverse valve pin	1
19	front bearing	1	43	air inlet bushing	1
20	front end plate	1	44	air inlet pin	1
21	cylinder	1	45	air closer	1
22	cylinder pin	2	46	spring	1
23	rotor	1	47	air inlet	1
24	rotor blade	6	48	filter	1